

Phase Failure, Phase Sequence, Under and Over Voltage plus Time Delay

Terminal Protection to IP20

43880

W. 17.5



Compact 17.5mm DIN rail housing

 \Box Microprocessor based

- True R.M.S. monitoring measuring phase to phase (3-wire) or phase to neutral (4-wire) voltages
- Selectable nominal voltages to suit most popular 3-wire or 4-wire supply voltages
- Monitors own supply and detects if one or more phases exceed the set Under or Over voltage trip levels
- Detects incorrect phase sequence, phase loss and neutral loss1
- Adjustments for Under and Over voltage trip levels
- Adjustment for Time delay
- Independent relay outputs - Under voltage monitoring (RLY2) / Over voltage monitoring (RLY1)
- 2 x SPDT relay output 5A
- Green LED indication for supply status \Box
- Individual Red LED indication for both relay statuses

¹ Only when 4-wire monitoring selected



FUNCTION DIAGRAM Under and Over Voltage Monitoring Over trip Monitored 3~ Supply Hyst. L2 L3 中 N Hyst. Under trip Output Td | t_r | | Td |

INSTALLATION AND SETTING

Installation work must be carried out by qualified personnel.

- BEFORE INSTALLATION, ISOLATE THE SUPPLY.
- Connect the unit as required. The Connection Diagram below shows a typical installation, whereby the supply to a load is being monitored by the Phase monitoring relay. If a fault should occur (i.e. fuse blowing), the relay will de-energise and assuming control of the external Contactor, de-energise the Contactor as well.
- Only connect the Neutral if available and 4-wire monitoring is required.

Applying power.

- Set the "Nominal (Un)" 4 voltage selector to match that of the voltage being monitored.
- Set the Over %" **⑤** adjustment to maximum and the "Under %" **⑦** adjustment to minimum. Set the "Delay (t)" 6 to minimum.
- Apply power and the green "Power supply" 1 LED will illuminate. Both the red "RLY1" 2/"RLY2" 2 LED's will illuminate and corresponding RLY1 and RLY2 relays energise after the short Power on delay (Td).
- Refer to the Troubleshooting table if the unit fails to operate correctly.

Setting the unit (with power applied).

- Set the "Over %" and the "Under %" adjustments to give the required monitoring range.
- If large supply variations are anticipated, the adjustments should be set further from the nominal voltage.
- Set the "Delay (t)" adjustment as required. (Note that the delay is only effective should the supply increase above or drop below the set trip levels. However, if during an under voltage condition the supply drops below the 2nd under voltage trip level, any set time delay is automatically cancelled and both relays de-energise immediately).


Troubleshooting.


The table below shows the status of the unit during a particular fault condition.


Supply fault	Green LED	Red LED	Red LED	Relay RLY1	Relay RLY2
Phase or neutral ² missing	Flashing ¹	Off	Flashing ¹	De-energised	De-energised
Phases reversed (no delay)	Flashing	Off	Off	De-energised	De-energised
Under voltage condition (during timing)	On	On	Flashing	Energised	En for delay (t)
Under voltage condition (after timing)	On	Off	Off	Energised	De-energised
Over voltage condition (during timing)	On	Flashing	On	En for delay (t)	Energised
Over voltage condition (after timing)	On	Off	On	De-energised	Energised
Phases < fixed under trip level [2]	On	Off	Off	De-energised	De-energised

TECHNICAL SPECIFICATION Supply/monitoring voltage Un 4-wire monitoring (L1, L2, L3, (N)): 110, 208, 220V AC 63.5, 120, 127V AC 380, 400, 415V AC 220, 230, 240V AC 48 – 63Hz LV: 70 – 286V Std: 243- 540V AC (L>L) Frequency range Supply variation: Overvoltage category: III (IFC 60664) Rated impulse withstand voltage 4kV (1.2/50µS) IEC 60664 Power consumption (max.) 2 5VA Monitoring mode Under and Over voltage Trip levels Fixed ± 2% see below Under [2]: Under: 75 - 95% of Un Over: 105 - 125% of Un ≈ 45V rms (ass ning balanced load across phases). Applies if unit set to: 220, 230 Neutral loss/shift detection threshold Under [2] Under Measuring ranges Nominal (Un) Over 3-wire (L>L) 110V 83 - 105V 116 - 138V 133V 156 – 198V 218 - 260V 208V 220V 140V 165 - 209V 231 - 275V 4-wire (L>N) 120V 76V 90 -114V 126 - 150V 127V 81V 95 - 121V 133 - 159V 400V 256V 300 - 380V420 - 500V 415V 265V 311 - 394V 436 - 519V 4-wire (L>N) 220V 140V 165 - 209V 231 - 275V 230\ 147V 173 - 219V 242 - 288V 252 - 300V ≈ 2% of trip level (factory set) Hysteresis: Setting accuracy Repeat accuracy: ± 0.5% at constant conditions Immunity from micro power cuts <50ms Response time (t_r): ≈ 50ms Time delay (t): 0.2-10s (\pm 5%) Note: actual delay (t) = adjustable delay + response tim Power on delay (Td): ≈ 1s (worst case = Td x 2) Reset time: 50 - 100ms Power on indication: Green LED Relay status indication Red LED x2 Ambient temperature: -20 to +60°C Relative humidity: +95% max Output (15, 16, 18 / 25, 26, 28) 2 x SPDT relay AC1 AC15 250V 5A (1250VA) 250V 2A DC1 25V 5A (125W) Electrical life: ≥ 150,000 ops at rated load Dielectric voltage: 2kV AC (rms) IEC 60947-1 4kV (1.2/50μS) IEC 60664 Rated impulse withstand voltage Orange flame retardant UL94 Housing: 90g On to 35mm symmetric DIN rail to BS EN 60715 or direct surface mounting was 2 x M3.5 or 4BA screws using black clips provided on the rear of the unit $\leq 2.5 mm^2$ solid or stranded Weight Mounting option: Terminal conductor size Terminal screw: M2.5 0.4Nm (3.5Lb-In) Max Tightening torque Conforms to IEC. Approvals: CE, Cand RoHS Compliant. (UL) LISTED EMC: Immunity: EN 61000-6-2 E ssions: EN 61000-6-4 Note: "L>L" has the same meaning as "phase to phase" and "L>N", the same as "phase to neutral









Broyce Control Ltd., Pool Street, Wolverhampton, West Midlands WV2 4HN. England

¹ Green and Red LED's alternate in this fault condition ² Refer to Technical Specification for neutral loss/shift threshold voltage